Nettletin CONCRETE, INC CONCRETE MASONRY UNITS - READY MIX



Unique Expressions in a Matrix of Stone & Mortar

Tumbleridge Nettlestone

Concrete Masonry's New Generation.

Custom 4" Tumbled Ashlar Veneer

Tumbleridge Nettlestone is a 4" Ashlar tumbled concrete veneer which is available in select predesigned color combinations.

Alternatively, numerous custom mingled color schemes may be produced to order, enabling the designer to select expressive color combinations that *enhance the project's architectural style*.

Tumbleridge Nettlestone's proprietary materials and manufacturing processes give the appearance of natural weathered stone by smoothing the jagged and rough split face of original Nettlestone. The *rustic yet refined appearance and textures* of Tumbleridge Nettlestone rival the spectacular beauty of Mother Nature, but at a much lower cost than stone.

The Tumbleridge Nettlestone System consists of 5 different sizes of units. Customize even more by selecting custom trim and accent units. The project designer has a *broad and versatile medium* in which to express their artistic vision.










Integral water repellent is added to each unit to help avoid effloresence and slow the aging process by preventing water penetration. A jobsite-applied coat of sealer not only enriches the color and appearance of the block, but provides added moisture protection for the block and mortar joints in the finished wall. When a water repellent mortar is used, the entire wall is capable of repelling water and providing lasting beauty.

Nettleton Concrete Masonry Veneers are designed to be installed using the proven conventional masonry method. This method provides a void between the veneer and the main structure which allows any moisture that penetrates or condenses to dissipate before causing any damage. Additionally, this void allows the veneer to react to temperature fluctuations with independent movement between it and the main structure. In contrast, other veneers that are directly adhered may detach when temperature differences force the veneer and structure to move at different rates and directions.



Color Selections



Huntcliff Hollow



Mediterannean Bay



Smoke House



Sierra



Wood Chase

Due to the nature of natural aggregates, some variation is to be expected. We recommend erecting a jobsite sample panel.





QUALITY PRACTICES

- DELIVERY, STORAGE, AND HANDLING OF CUSTOM CONCRETE MASONRY UNITS (CCMU)

- DELIVERY, STORAGE, AND HANDLING OF CUSTOM CONCRETE MASORIET URITS (CCMU)
 Palletized CCMU should not be stacked on top of each other.

 CCMU should be laid in wall ASAP to minimize the introduction of moisture into the units.

 Keep CCMU covered at all times to prevent rain penetration that will cause efflorescence to be visible.

 Efflorescence is primarily calcium that is released when concrete curres. Moisture enables the calcium to leach to the surface when moisture is present.

 Nettleton Concrete recommends the erection of sample panels that are representative of materials and workmanship. The size of the panel should be of sufficient size to demonstrate the architectural style/design of the project.

- INSTALLATION
 Keep walls covered at the end of each day and/or during rain to prevent efflorescence and color variation caused by moisture entering the wall cavity.

 Lay units from more than one pailet a time during installation and using the best concrete masonry practices.

 A water repellant mortar admixture should be used in mortar to ensure the highest level of water repellency of CCMU masonry wall.

 Nettleton Concrete uses water repellant in the manufacturing of all CCMU. Use proper flashing to prevent

- Nettleron Concrete uses water repenant mane management of the control of the cont
- moisture.
 It is generally recommended that joints be tooled when the mortar reaches "thumbprint hardness". Tooling the mortar too soon lightens the color and strinkage cracks may occur. Tooling it too late may cause the mortar not to seal properly against the masonry units and the color will be darker.

 Concrete grout used in the CCMU should be low slump. Concrete should not contain excessive water that can "bleed through" the interior and exterior of the masonry wall causing efflorescence. If a higher slump, more flow-able mix is required, Nettleton Concrete recommends the use of a super plasticizer admixture.

 Precautions must be taken when sawing CCMU. Please consult our SDS sheets on the materials and use the appropriate Personal Protection Equipment, (PPE), CCMU may be stained by masonry dust and pigments from sawing. CCMU should be properly cleaned before installing.

 Brush walls down daily with stiff bristled non metallic brush to prevent mortar from drying on the face.

 CLEANING

- CLEANING
 CCMU must be cleaned properly including mortar droppings, mortar splatters and efforescence. Improper cleaning materials and/or methods will also harm water repellency.
 DO NOT USE WATER RRESSURES HIGHER THAN MUNICIPAL WATER PRESSURE Using high pressure will most likely cause efflorescence, streaking, and color variation. USE OF PRESSURE HIGHER THAN MUNICIPAL WATER PRESSURE RELIEVES NETTLETON CONCRETE OF ANY LIABILITY.
 Nettleton Concrete recommends that you use masonny cleaner to clean CCMU. Your Nettleton Concrete representative can help supply you with a cleaning agent and it can ship with your CCMU to your jobsite.
 Consistent application of water and cleaner on the wall system will ensure consistent color after completion of cleaning. Inconsistent application will cause color variation.
 EFFLORESENCE STAINING
 Keen all sprinklers from causing water to contact CCMU.

- EFFLORESENCE STAINING
 Keep all sprinklers from causing water to contact CCMU.
 Wet mud or bark will cause efflorescence staining of CCMU Nettleton Concrete recommends hay or straw placed at foundation to help prevent this.
 Staining below window sills, metal brackets, and vents that attach to the walls, etc., can be avoided by having projections carried out at least one inch from the face of the wall with a drip notch or groove on the underside in order to keep water from running back under sill and down the face of the wall and onto metal devices or other stain producing items attached to wall. These items should be insulated from the visible portion of the wall by a non-staining gasket material having a drip to divert potential staining material away from the wall.
- Notificing Concrete uses the most economical high-quality consistent aggregates available for manufacturing. These are all natural mined materials and are subject to variation. Solid units, due to moisture, may appear darker than cored units.

 Large segments of smooth face units will accent color and texture variation of the natural materials more than split-face

- Special care should be taken to lay CCMU in the same direction/orientation to maintain proper shade and texture
- appearance
 Due to changes in mined material, color variation should be expected in CCMU produced at different times. Ex: additions, change order, etc.
 Nettleton Concrete does not manufacture each order at the same time, but will generally produce the order during a 1 week period, depending on size, weather permitting.
 WATER REPELLENCY

- Water Repellency should not be confused with water proofing. Nettleton Concrete CCMU have integral water repellant added at the time of production. Generally West and Southwest facing walls are more subject to extra moisture because of the natural flow of the JET stream. Therefore, Nettleton Concrete recommends that all exterior walls be treated with a sealer: to provide the highest level of water repellency.

 SEALER
- SEALER
 The use of any sealer on block surface should be carefully considered. If the sealer is applied to a wall that still contains the basic ingredients for efflorescence (moisture) the resulting problems could be severe. As the salt solution attempts to migrate toward the surface, most of the salts become trapped in the concrete pores just inside the sealer. The result is an interior crystalline buildup called subflorescence which can exert considerable pressure and spall the unit face. If required the following should be considered:

 i. Block sealer shall not be applied until the wall has dried out a minimum of 72 hours without rain and there is no visible sign of efflorescence on the wall.

 ii. Make sure to apply materials in accordance with manufacturers printed instructions.

 iii. Sealers should be applied evenly without overlapping. Uneven application of sealers can discolor CCMU.

 IV. Apply a second coat of sealer to masonry surfaces that are propos.

 V. All windows must be covered and all cars removed before spraying as glass and finished metal can be damaged.

 Sealers are extremely hard if not impossible to remove from glass.

SPECIFICATIONS **Tumbleridge Nettlestone**

Part 1 - General

accordance with Section 0.1350 submittal procedures, submit color samples for selection from manufacturer's ries. Submit product literature, certifications, test reports and full size sample(s) of each color specified. ovide current integral water repellent CMU producer qualification.

QUALITY ASSURANCE
Certifications (Tumbleridge Finishes): Tumbleridge Nettlestone units are hollow and solid non-load bearing
concrete masorny units of multiple sizes with faces that are either split utilizing blades exerting pressure from allfour sides of product, or Tumbleridge utilizing a drum roller after product has been split. Units are manufactured
by means of moisture controlled curing for 24 hours minimum. Concrete blocks for finishing shall conform to
ASTM C90 for Normal Weighth All units contain an integral water repetant CMJ admixture at the time of manufacture. Units shall conform to ASTM C744 with respect to abrasion, crazing resistance, and color change.
Field Constructed Mock-Ups; Construct a sample panel no less than 4* 8° containing each color and size units
to be used in the project illustrating color, clear sealer finish, texture, and mortar joints to establish a standard of
quality for completed work. Mock-Up shall also illustrate Nettlestone and mortar combination, coursing, bond,
unit size ratio, and pattern. Retain mock-up during construction as a quality standard. Completely remove when
work is accepted.

Nettlestone units shall be delivered on covered wood pallets in such a way as to protect faces. Store in protected area and covered to ensure units remain dry and clean. Do not allow units to sit in standing water. Handle masonry units in manner to avoid chipping, breaking, contact with contaminating materials, and marring of faces.

Part 2 - Products

PRODUCT NAME

MANUFACTURER

Nettleton Concrete, Inc. (800) 382-2462 2318 Moore Road Jonesboro, Arkansas 72401 RELATED MATERIALS

Colored matching or contrasting mortar is available from the manufacturer. For all exterior mortar, use matching manufacturer approved water-repellent mortar additive, following manufacturer's instructions.

Nettlestone consists of Ashlar units of multiple sizes that can be used in the assembly of a CMU wall system. Nominal 4" standard block thicknesses are available. Custom sill units of varying sizes are also available. WATER REPELLENCY

Notifies for Units are manufactured with RainBloc® integral water repellent, or approved equal, to assist in controlling efflorescence. Use of RainBloc® mortar admixture, or approved equal, is required for a water repellent.

Use masoriny cleaners such as Custom Masonry Cleaner, manufactured by Prosoco, Inc., or approved equal for all finishes. Do not apply cleaner with a pressure sprayer above 50psi.

INSTALLATION

INSTALLATION Install Nettlestone as part of unit masonry work specified in Section 04850 - Unit Masonry Assemblies. Always lay blocks from more than one pallet at a time during installation. Complete masonry construction using proce-dures and workmanship consistent with quality masonry practices. Cutting: Field cut Nettlestone with motor-driven masonry saws using an abrasive or diamond blade to provide straight true edges and avoid damage to face. Field split Nettlestone comers with suitable tools to insure uniform texture and consistency of face. Do not install chipped or broken units. Mortar Bedding and Jointing. All mortar joints should be tuckpointed for the appropriate appearance. For external applications, tuckpoint joints to control water penetration. Raked joints are not recommended for any applications, tuckpoint joints to control water penetration.

application.

Protection: During erection, cover top of walls with waterproof sheeting at end of each day. Cover partially completed walls when work is not in progress. Extend cover 24 inches minimum down both sides and hold securely in place. Protect face of walls, sills, and other projections from roof run-off, splashed water, mud, grout, and morths. Spread sand or straw at base of walls to minimize dirt and clay splashing onto faces. Without damaging completed work, it is recommended to provide protective boards at exposed external corners which may be damaged by construction activities.

Faces of units exposed in finished work shall be of uniform color and texture and free of chips, cracks, or other imperfections detracting from appearance of the finished wall when viewed from a distance of fifteen (15) feet at right angles to the wall under normal lighting conditions.

FLASHING OF MASONRY WORK
Install flashing at locations shown in the plans and in strict accordance with the details and quality masonry flashing practices.

Install weep holes and vents at proper intervals at courses above grade, above flashing, and at any water stops over windows, doors and beams.

Exercise care that wet mortar is not splashed onto Nettlestone during installation. Excess or splashed mortar shall be cleaned from face with dry buriap wipe or masonry brush. Remove after mortar becomes hard enough not to smear but prior to mortar setting.

Clean completed wall surfaces using masonry cleaners such as Custom Masonry Cleaner, manufactured by Prosoco, Inc. Dilute cleaning solution as recommended by manufacturer. Strictly follow manufacturers cleanin-instructions. Do not use acid or abrasives on finished surfaces. Do not powerwash, High pressure powerwash-ing may interfere with performance of the integral water repellent causing efflorescence.

Nettlestone, properly installed, cleaned, and sealed, needs virtually no maintenance other than routine cleaning with standard commercial grade cleaning agents. Contact manufacturer for specific cleaning recommendations.

